NAUGHTY BOY

OPERATION AND MAINTENANCE MANUAL

CINEMATRONICS, INC. 1841 FRIENDSHIP DRIVE EL CAJON, CA 92020 (714) 562-7000

TELEX: CINEMAT ELCJ 697891
CALL TOLL FREE: (800) 854-2666

IN CALIFORNIA CALL: (714) 562-7000

SALES: 8-5 (PST) WEEKDAYS SERVICE: 8-5 (PST) WEEKDAYS

NAUGHTY BOY

GAME MANUAL

TABLE OF CONTENTS

	PAGE
FCC WARNING	1
WARRANTY	2
CUSTOMER SERVICE PROCEDURES	3
RECEIVING AND INSTALLING	5
NAUGHTY BOY - GAME DESCRIPTION	6
OPTION SWITCH SETTINGS	10
ROUTINE MAINTENANCE	11
WELLS-GARDNER COLOR MONITOR INFORMATION	12
PARTS LIST - GAME ASSEMBLY	28
PARTS LIST - ELECTRONIC BOARDS	39
BOARD EDGE CONNECTOR PIN-OUT LIST	43
APPENDIX A -	

ASSEMBLY DRAWINGS AND SCHEMATICS:
ELECTRONIC BOARD LAYOUTS AND SCHEMATICS
GAME ASSEMBLY DRAWINGS, SCHEMATICS AND HARNESS WIRE
LISTS

CINEMATRONICS, INC.

WARNING:

This equipment generates, uses, and can radiate radio frequency energy; and, if not installed and used in accordance with the Instruction's Manual, may cause interference to radio communication. As temporarily permitted by regulation, it has not been tested for compliance pursuant to Subpart J of Part 15 of FCC rules, which is designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

WARRANTY

Cinematronics, Inc. warrants the goods to be free from defects in material and workmanship under normal use and service for a period of ninety (90) days from the date of shipment from factory. Cinematronics makes no representation or warranties concerning the goods whether express or implied by operation of law or otherwise, including those of merchantability or fitness for any particular purpose, or with respect of patent infringement, except as may be specifically made herein. Cinematronics limits its warranty obligations herein to the repair or replacement of such parts which have been returned to Cinematronics' plant at purchaser's expense and which examination shall disclose Cinematronics' satisfaction to have been so defective and to the shipment of such repaired or replacement parts to the purchaser F.O.B. the shipping point.

This warranty does not apply to any Cinematronics' product which has been altered or repaired by unauthorized personnel or service facilities or any products which have had the unit serial number altered or removed.

Upon acceptance of the goods, the purchaser agrees to assume all liability for damages and/or bodily injury by the purchaser or any other person and to hold Cinematronics, Inc. harmless from liability or claims arising from the use of the goods by any person. Purchaser further agrees to indemnify Cinematronics, Inc. from any liability, claim, cause of action or litigation resulting from the use or misuse of the goods by any person.

Parts returned for warranty service must be packaged so that no damage is incurred during the shipment. Fu'l documentation and instructions must accompany returned parts. Parts must be shipped prepaid to:

> Cinematronics, Inc. 1841 Friendship Drive El Cajon, CA 92020

CUSTOMER SERVICE PROCEDURES FOR AUTHORIZED CINEMATRONICS' DISTRIBUTORS

It is the desire of Cinematronics, Inc. to provide efficient and courteous service should the need arise. We have a fully staffed Customer Service Department and encourage you to call our toll-free number: (800) 854-2666 for technical assistance between the hours of 8:00 A.M. and 5:00 P.M., California time, Monday through Friday.

In order to provide the very best service possible, the following procedure for ordering or returning parts must be followed:

- l. All equipment ordered from Customer Service, whether in or out of Warranty, must be placed with a Distributor's purchase order, either by mail or verbally by telephone.
- 2. Advance replacement items may be obtained only during the term of the Warranty and when such items are available, using the same procedure as when ordering parts. When ordering a PCB, please include with your order the game serial number and the number of the PCB you wish replaced.
- 3. All items received as advance replacements will, after a period of thirty (30) days, become the property of the Distributor, with applicable charges applied in the event Customer Service has not received the defective item against which the advance replacement was made.
- 4. The Distributor must call this facility for an RMA number prior to returning any item. Please be prepared to provide us with the game serial number and the PCB number when requesting an RMA.
- 5. In all situations covered above, and in all other situations, the Warranty offered by Cinematronics, Inc. is applicable and should be fully understood.
- 6. Parts returned for service must be packaged so that no damage is incurred during the shipment. Cartons without a prominently displayed RMA number will not be accepted. Full

documentation including game serial number, PCB number on outside of package, and reason for return must accompany parts. Ship prepared to:

Cinematronics, Inc.
Customer Service Department
1841 Friendship Drive
El Cajon, CA 92020

(800) 854-2666

(714) 562-7000

RECEIVING AND INSTALLING

RECEIVING INSPECTION

Your game was shipped in ready-to-play condition. However, after removal of the shipping carton, a brief visual examination is suggested.

Naturally, you will want to make note of any physical damage to the game cabinet and its external components for freight claim purposes. Considering the quality of the shipping carton, any damage to the exterior would indicate possible interior damage as well.

The interior of the game should also undergo a brief examination for: loose mounting hardware (check to be sure that the major components are still securely mounted); disconnected or loose wires, cables or harnesses; electronic devices loose in their sockets; etc.

At this time the game serial number should be logged. Remember that the game serial number will be required if you need service from your distributor. Please complete the postage-free reply card and mail immediately.

ELECTRICAL REQUIREMENTS

Unless specified otherwise, your game was shipped to operate at 115 VAC, 50/60 Hz.

A good earth ground is essential for the proper operation of this game or for that matter, any electronic device. Problems with instability and erratic operation of computer-type devices can usually be traced to an ineffective ground system. Therefore, plug the game into a properly wired three prong outlet. If a three prong to a two prong AC adaptor must be used, an alternate method of grounding the third prong must be used.

NAUGHTY BOY GAME DESCRIPTION

GAME PLAY

Game play for Naughty Boy proceeds through four different screens. These screens will appear in sequence. Each time a player successfully maneuvers through all four screens, the screens repeat their appearance, with more objects moving at higher speeds. In addition, after successfully completing even numbered rounds, the player is awarded a bonus round.

SCREEN ONE

This screen begins with Naughty Boy standing in a forest. In front of him are several monsters. There is also a safety zone that can be entered through two red doors, which the monsters cannot enter. The same type of doors appear on fences along the side of the screen. Naughty Boy can appear on the other side of the screen by passing through one of these doors.

As Naughty Boy moves towards the top of the screen, the images scroll downwards. Above the forest is a series of fences, then a group of ponds, and finally, walls of a fortress. Some goblins guard the top portion of the screen.

Naughty Boy must maneuver his way through the forest, past the fences and ponds and destroy the flags that are flying on the fortress. The player controls Naughty Boy with a four position joystick. In addition, a throw button allows the player to throw rocks at objects to destroy them.

Naughty Boy must avoid contact with the monsters and goblins or he will be destroyed. Also, a dragon will randomly appear on the ponds breathing fire. If Naughty Boy is hit by the fire, he will be destroyed.

The safety zone allows Naughty Boy to attack the monsters and goblins without danger by throwing rocks at them outside. A timer begins to decrease whenever Naughty Boy is inside the

safety zone. Once the timer reaches zero, the red doors disappear and Naughty Boy can be attacked.

Periodically, a question mark will appear on the screen. If Naughty Boy hits the question mark with a rock, he will become invincible to attack from the monsters and goblins for a short time. Naughty Boy can still be destroyed by the dragon. After the question mark is hit, different objects will appear in the same spot. These objects will score bonus points when hit with rocks.

Once Naughty Boy reaches the fortress, he must hit all the flags with rocks. Two flags can be destroyed with one throw, if the rock lands in between two flags. Once all the flags are destroyed, Naughty Boy will proceed to the next screen.

If Naughty Boy is destroyed before he is able to destroy all the flags, he will reappear at the starting position of the screen he is currently in. Any flags destroyed by Naughty Boy remain destroyed.

Naughty Boy always throws in the direction that he is facing. The distance a rock is thrown is determined by how long the throw button is depressed.

SCREEN TWO

This screen is an open field. A safety zone is in the center of the field. Monsters and goblins are scattered around the field. Robots guard the fortress at the top of the screen.

Play proceeds as in the first screen. The dragon appears randomly in the field above the safety zone. Once all the flags are destroyed, Naughty Boy will appear in the next screen.

SCREEN THREE

Naughty Boy begins his adventure in the center of a maze. Goblins and monsters will chase Naughty Boy through the maze. At the top of the maze is the safety zone. Above the safety zone is the fortress. No dragons appear in this screen.

SCREEN FOUR

In this screen Naughty Boy is standing between the safety zone and some ponds. The dragon will randomly appear in the ponds. Above the ponds is a series of fences and walls. Once Naughty Boy passes through these, he reaches the fortress.

If all the flags are destroyed in this screen, Naughty Boy will appear in Screen One. However, Naughty Boy must fight more objects which are moving faster. This is true for every screen that Naughty Boy goes through.

BONUS PLAY

After successfully completing even numbered rounds, the player is given a bonus play. During bonus play, Naughty Boy flies back and forth at the top of the screen in a balloon. A fuel gauge above the balloon indicates how much bonus play is left. At the bottom of the screen, a female monster runs back and forth.

Naughty Boy throws objects out of the balloon and tries to hit the monster on the head. If the monster is struck, she changes expressions momentarily. The fuel gauge decreases as play proceeds. Play continues until the fuel runs out.

Play continues until all of a player's Naughty Boys are destroyed. A player can earn one extra Naughty Boy based upon his score achieved and the operator adjustable level selected.

SCORING

Monsters, Goblins & Robots - 250 Points to 9000 Points

Flags - 200 Points to 2000 Points

Bonus Objects - 500 Points to 9000 Points

FEATURES

- 1. Number of Naughty Boys per game operator adjustable is 2, 3, 4 or 5.
- 2. Point level at which the extra Naughty Boy is awarded is operator adjustable at 10,000, 30,000, 50,000 or 70,000 points.

- 3. Four coinage options.
- 4. Easy/hard switch for longer game life.
- 5. Four different screens and bonus play round.
- 6. Fifty difficulty levels.
- 7. Throw distance controlled by the throw button.

NAUGHTY BOY OPTION SWITCH SETTINGS

OPTION	FACTORY SETTING	DESCRIPTION	1	2	3	4	5	6	7	8
NUMBER OF NAUGHTY BOYS		2	ON	ON						
	х	3	OFF	ON						
•		4	ON	OFF						
		5	OFF	OFF						
EXTRA BOY		10,000 Points			ON	ON				
	x	30,000 Points			OFF	ON				
		50,000 Points	*		ON	OFF				
		70,000 Points			OFF	OFF				
CREDITS		2 Coin, l Play					ON	ON		
	х	l Coin, l Play		1			OFF	ON		
		l Coin, 2 Play					ON	OFF		
		4 Coin, 3 Play					OFF	OFF		
DIFFICULTY	х	Easier							ON	
		Harder							OFF	
GAME TYPE		Upright								ON
		Cocktail			T					OFF

ROUTINE MAINTENANCE & SERVICE

Because of the solid state electronic circuitry, this machine should require very little maintenance and only occasional adjustments. However, it is necessary to take measures to ensure this.

The volume control is located on the rear of the coin door and can be accessed by opening the coin door.

The video monitor has been properly adjusted before shipping. Occasionally minor adjustments are necessary. See monitor specifications and schematics for technical information. Adjustment controls for the monitor are located at the rear of the monitor.

This machine should be serviced only by a qualified technician.

Do not make any adjustments on this machine while the power is on.

For service information, contact:

CINEMATRONICS, INC.
1841 FRIENDSHIP DRIVE
EL CAJON, CA 92020
(714) 562-7000

POWER SUPPLY

The computer board in this game operates most efficiently and reliably when the power supply is set so that the voltage on the board is 5.0 volts, -0.1 volts. To check this, place a meter across 5 volts and ground at the edge connector. If necessary, adjust the screwdriver control on the power supply so the meter reads between 4.9 and 5.1 volts.

NAUGHTY BOY

PARTS LISTS

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
38-10640-01	Assy, Fluorescent Lamp	1
01-10505-01	Lamp, Fluorescent	1
26-10588-01	Fixture, Lamp, Fluorescent	1
87-11668-01	Assy, Harn Fluorescent Lamp	1
25-10579-01	Ty Rap, W/O Eyelet	7
25-10580-01	Ty Rap, W/Eyelet	3
34-11271-01	Wire, 18AWG, Twtd, Blk/Wht	
35-10614-01	Pin, Male, Molex	2
38-11698-02	Assy, Coin Door W/Lamps	1
20-10896-11	Coin Door W/Lamps Cocktail	1
22-10899-01	Decal, "Cinematronics"	1
25-10556-01	Nut, Hex #4-40	3
25-10570-01	Washer, Lock #4 Internal	3
38-11702-02	Assy, Coin Meter/Vol Ctl	1
20-10868-11	Brkt, Short Vol. Cntl/Counter	1
25-10557-01	Nut, Hex #6-32	2
25-10563-01	Screw, Machine, #6-32 x 1/2" Pan Hd P	2
25-10571-01	Washer, Lock, #6 Internal	2
38-11757-01	Assy, Coin Meter	1
29-11754-01	Meter, Coin 6 Volt (KEISU NR-06)	1
35-10614-01	Pin, Male, Molex	2
38-10961-04	Assy, Vol Ctl	1
26-10589-01	Knob, Volume	1
51-10722-01	Pot, W. Lk. Wsr/Nut, 10K Ohm	1
87-10955-01	Assy, Har, Vol Ctl	1
34-11719-01	Wire, 22AWG Blue/Red/Blk Twist	
35-10614-01	Pin, Male, Molex	1
35-10615-01	Pin, Female, Molex	2
87-11680-01	Assy, Harn Coin Door	$\frac{1}{4}$
25-10579-01	Ty Rap, W/O Eyelet	1
25-10905-01	Clamp, Cable 3/16", Plastic	4
34-10597-01 34-10599-01	Wire, 22AWG, Blk Wire, 22AWG, Yellow	
34-10603-01	Wire, 22AWG, Grey	
34-10906-01	Wire, 22AWG, Twisted, Brown/White	
41-10885-01	Conn, 9 Cir F, Molex 03-09-2092	1

CINDMARDONICO		
CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
38-11434-01	Assy, Monitor, Color Raster	1
87-11711-01	Assy, Harn Raster Mon to CPU	1
34-10597-01	Wire, 22AWG, Blk	$\frac{1}{2}$
34-10606-01	Wire, 22AWG, Red	
34-10598-01	Wire, 22AWG, Green	
34-10605-01	Wire, 22AWG, Blue	
34-10607-01	Wire, 22AWG, White	
35-10614-01	Pin, Male, Molex	5
35-10615-01	Pin, Female, Molex	7
41-10954-01	Conn, 6 Cir F, Molex 03-09-2062	1
41-10651-01	Conn, Female Crimp Term, Molex	1
41-11724-01	Conn, 6 Cir Crimp Term 09-50-7061	1
25-10579-01	Ty Rap, W/O Eyelet	3
38-11737-01	Assy, Circuit Panel	1
38-11733-02	Assy, Boards W/Vol Mod	1
38-11738-02	Assy, Board MT-09 W/Vol Mod	1
34-10594-01	Wire, 30AWG, Blue, KYNAR	
63-10781-01	Cap, .005mf 50V DISC 20%	1
38-11738-01	Assy, Board MT-09	1
38-11739-01	Assy, Board MT-10	1
20-11687-01	Plate, Mntg Logic/Audio	1
25-10557-01	Nut, Hex #6-32	4
25-11756-01	Screw, Machine #6-32 x 2" PH PN	4
25-11752-01	Washer, #6 Lock (Split Ring)	4
25-11753-01	Spacer, Nylon #6-5/8" (Smith 4025)	8
25-11749-01	Washer, #6 Flat	4
32-11736-01	Cabinet, Upright Color Raster SH	1
38-11673-01	Assy, Ctl Pnl	1
20-11673-01	Ctl Pnl	1
22-11674-01	Decal, Ctl Pnl	1
37-11192-01	Button, Short, White, Cocktail	2
37-11192-02	Button, Short, Red	1

PART NUMBER	DESCRIPTION	QTY.
37-11373-01	Switch, W/Plastic Mntg Brkt, Short	3
25-10559-01	Nut, Pal 5/8"	3
25-10558-01	Nut, Hex, #10-24	4
25-10572-01	Washer, Lock, #10 Internal	8
25-10909-01	Bolt, Carriage, 3/16" x 3/4", Blk OX	4
50-11763-01	Assy, Joystick 4 Pos WICO 15-9518	1
25-11688-01	Screw, Machine 8-32 x 1/2"	4
87-11679-01	Assy, Harn Ctl Pnl	1_
34-10596-01	Wire, 22AWG/TC, Buss	
34-10597-01	Wire, 22AWG, Blk	
34-10607-01	Wire, 22AWG, White	
34-10598-01	Wire, 22AWG, Green	
34-10600-01	Wire, 22AWG, Purple	
34-10599-01	Wire, 22AWG, Yellow	
34-10603-01	Wire, 22AWG, Grey	
34-10604-01	Wire, 22AWG, Brown	
34-10605-01	Wire, 22AWG, Blue	
34-10602-01	Wire, 22AWG, Orange	
35-10614-01	Pin, Male, Molex	9
41-10885-01	Conn, 9 Cir F, Molex 03-09-2092	1
25-10579-01	Ty Rap, W/O Eyelet	8
23-11152-01	Tape, Foam 3/4"	
38-10894-01	Assy, Coin Drawer	1
20-10862-01	Brkt, Coin Box Tong	1
20-10864-01	Handle, Coin Box	1
20-10871-01	Coin Box	1
20-10872-01	Cover, Coin Box	1
38-11700-01	Assy, P.S./Transformer (Raster)	1
20-11606-01	Plate, Mtg, P/S, Transformer	1
25-10551-01	Bolt, Carriage, 3/16" x 1/2" Black O	8
25-11607-01	Stand-Off, Nylon, Locking, DLCBS-14	4
25-11612-01	Washer, Lock #8	8
25-11613-01	Nut, #8-32	8

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
38-11723-01	Assy, Transformer ISOL Ravenswood	1
43-11704-01	Transformer, ISOL Ravenswood	$\frac{1}{1}$
87-11688-01	Assy, Harn Trans/Monitor	
87-11768-01	Assy, Harn Trans/P.S.	$\frac{\frac{1}{1}}{\frac{1}{2}}$
87-11767-01	Assy, Harn Trans Gnd.	1
81-11685-01	PCA, Regulator +12V, -5V	$\frac{1}{1}$
20-10520-01	Heat Sink, Thermalloy 6071B	2
20-10521-01	Heat Sink, Thermalloy 6072B	2
25-10556-01	Nut, Hex #4-40	4
25-10570-01	Washer, Lock, #4 Internal	4
25-10974-01	Screw, Machine 4-40-3/8" Pan HD PH	4
41-10661-01	Conn, 6 Cir WAF, Molex 09-18-506	1
53-10732-01	Res, 470 Ohm 1/4W 5% C	1
53-10734-01	Res, 1K Ohm 1/4W 5% C	1
53-11707-01	Res, 150 Ohm 5W Ceramic "Block"	3
63-10784-01	Cap, .1mf 50V Disc 20%	4
63-11128-01	Cap, 22mf 50V Electrolytic Radial	3
65-10812-01	Diode, 1N4003, Encpl	4
66-11705-01	Trans, 7812	1
66-11706-01	Trans, 7905	1
80-11685-01	PCB, Regulator +12V, -5V	1
82-10842-30	Power Supply, Data Power	1
38-10638-01	Assy, Speaker	1
20-11382-01	Grill, Speaker	
71-10834-01	Speaker	1
\I 10034-01	Sheaver	1
87-11681-02	Assy, Harn Main W/Conn	1
87-11681-01	Assy, Harn Main	1
34-10597-01	Wire, 22AWG, Blk	
34-10598-01	Wire, 22AWG, Green	
34-10599-01	Wire, 22AWG, Yellow	
34-10600-01	Wire, 22AWG, Purple	
34-10602-01	Wire, 22AWG, Orange	
34-10603-01	Wire, 22AWG, Grey	

CINEMATRONICS - PART NUMBER	DESCRIPTION	QTY.
34-10604-01	Wire, 22AWG, Brown	
34-10605-01	Wire, 22AWG, Blue	
34-10606-01	Wire, 22AWG, Red	
34-10607-01	Wire, 22AWG, White	
34-10608-01	Wire, 18AWG, Red	
34-10610-01	Wire, 18AWG, Black	
34-11407-01	Wire, 18AWG, Yellow	
35-10614-01	Pin, Male, Molex	15
35-10615-01	Pin, Female, Molex	14
41-11746-01	Conn, Edge 36P Sullins EZM18DSEH	1
41-10649-01	Conn, 9 Cir M, Molex 03-09-1093	1
41-10648-01	Conn, 15 Cir F, Molex 03-09-2153	1
41-10883-01	Conn, 3 Cir M, Molex 03-09-1038	1
41-10647-01	Conn, 12 Cir M, Molex 03-09-1122	1
41-10657-01	Conn, 6 Cir M, Molex 03-09-1063	1
87-11677-01	Assy, Harn Ctl Pnl Interface	1
34-10597-01	Wire, 22AWG, BLK	_
34-10607-01	Wire, 22AWG, White	
34-10598-01	Wire, 22AWG, Green	1
34-10600-01	Wire, 22AWG, Purple	
34-10599-01	Wire, 22AWG, Yellow	
34-10603-01	Wire, 22AWG, Grey	
34-10604-01	Wire, 22AWG, Brown	
34-10605-01	Wire, 22AWG, Blue	
34-10602-01	Wire, 22AWG, Orange	
35-10615-01	Pin, Female, Molex	18
41-10660-01	Conn, 15 Cir M, Molex 03-09-1152	1
41-10649-01	Conn, 9 Cir M, Molex 03-09-1093	1
25-10579-01	Ty Rap, W/O Eyelet	6
25-10580-01	Ty Rap, W/Eyelet	3

25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10610-01 Wire, 18AWG, Blue 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk	QTY.
34-10597-01 34-10599-01 34-10600-01 34-10606-01 34-11719-01 41-10885-01 41-10649-01 35-10615-01 25-10580-01 34-10608-01 34-10609-01 34-10609-01 34-10608-01 34-10608-01 34-10608-01 34-10609-01 34-10609-01 34-10608-01 34-106	1
34-10599-01 34-10600-01 34-10606-01 34-10606-01 Wire, 22AWG, Purple Wire, 22AWG, Red Wire, 22AWG Blu/Red/Blk Twist Conn, 9 Cir F, Molex 03-09-2092 41-10649-01 35-10614-01 35-10615-01 Pin, Male, Molex Pin, Female, Molex Ty Rap, W/O Eyelet Ty Rap, W/Eyelet 87-11701-01 Assy, AC Power Cord Harn Nut, Wire 25-10580-01 Ty Rap, W/Eyelet Ty Rap, W/Eyelet Wire, 18AWG, Red Wire, 18AWG, Blue Wire, 18AWG, Blue Wire, 18AWG, Orange Wire, 18AWG, Brown Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex Ty Rap, W/Eyelet Ty Rap, W/Eyelet Wire, 18AWG, Blue Wire, 18AWG, Brown Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex	_
34-10600-01 34-10606-01 34-11719-01 Wire, 22AWG, Red Wire, 22AWG Blu/Red/Blk Twist Conn, 9 Cir F, Molex 03-09-2092 41-10649-01 Conn, 9 Cir M, Molex 03-09-1093 Pin, Male, Molex Pin, Female, Molex Ty Rap, W/O Eyelet Ty Rap, W/Eyelet 87-11701-01 Assy, AC Power Cord Harn Nut, Wire Ty Rap, W/Eyelet Wire, 18AWG, Red Wire, 18AWG, Blue Wire, 18AWG, Black Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex Ty Rap, W/Eyelet Wire, 18AWG, Blue Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex	
34-10606-01 34-11719-01 Wire, 22AWG, Red Wire, 22AWG Blu/Red/Blk Twist Conn, 9 Cir F, Molex 03-09-2092 Conn, 9 Cir M, Molex 03-09-1093 Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex Ty Rap, W/O Eyelet Ty Rap, W/Eyelet 87-11701-01 Assy, AC Power Cord Harn Nut, Wire Ty Rap, W/Eyelet Ty Rap, W/Eyelet Ty Rap, W/Eyelet 34-10608-01 Ty Rap, W/Eyelet 34-10609-01 Wire, 18AWG, Red Wire, 18AWG, Blue Wire, 18AWG, Black Wire, 18AWG, Orange Wire, 18AWG, Brown Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex Pin, Female, Molex Pin, Female, Molex	
34-11719-01 Wire, 22AWG Blu/Red/Blk Twist 41-10885-01 Conn, 9 Cir F, Molex 03-09-2092 41-10649-01 Conn, 9 Cir M, Molex 03-09-1093 35-10614-01 Pin, Male, Molex 35-10615-01 Pin, Female, Molex 25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Assy, AC Power Cord Harn Nut, Wire Ty Rap, W/O Eyelet 25-10579-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10609-01 Wire, 18AWG, Blue 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex	
41-10885-01 41-10649-01 35-10614-01 35-10615-01 25-10579-01 25-10580-01 Ty Rap, W/O Eyelet 87-11701-01 Assy, AC Power Cord Harn Nut, Wire 25-10580-01 Ty Rap, W/Eyelet 41-10608-01 34-10609-01 34-10610-01 34-1187-01 34-11718-01 34-10614-01 34-11187-01 34-11718-01 34-10614-01 34-10614-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 34-11187-01 35-10614-01 35-10615-01 None Female, Molex Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex	
41-10649-01 35-10614-01 Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex Ty Rap, W/O Eyelet Ty Rap, W/Eyelet 87-11701-01 Assy, AC Power Cord Harn Nut, Wire Ty Rap, W/Eyelet Ty Rap, W/Eyelet 25-10580-01 Ty Rap, W/O Eyelet Ty Rap, W/Eyelet 41-10608-01 Ty Rap, W/Eyelet Wire, 18AWG, Red Wire, 18AWG, Blue Wire, 18AWG, Black Wire, 18AWG, Orange Wire, 18AWG, Orange Wire, 18AWG, Brown Wire, 18AWG, Brown Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex Pin, Female, Molex	1
35-10614-01 Pin, Male, Molex 35-10615-01 Pin, Female, Molex 25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Assy, AC Power Cord Harn 25-10561-01 Nut, Wire 25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10609-01 Wire, 18AWG, Blue 34-10610-01 Wire, 18AWG, Black 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex 35-10615-01 Pin, Female, Molex	1
25-10579-01 25-10580-01 Ty Rap, W/O Eyelet 87-11701-01 Assy, AC Power Cord Harn Nut, Wire 25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10609-01 Wire, 18AWG, Blue 34-10610-01 Wire, 18AWG, Orange Wire, 18AWG, Orange Wire, 18AWG, Black Wire, 18AWG, Blu/Black Wire, 18AWG, Blu/Blk Pin, Male, Molex Pin, Female, Molex	9
25-10579-01 25-10580-01 Ty Rap, W/Eyelet Assy, AC Power Cord Harn Nut, Wire Ty Rap, W/O Eyelet Ty Rap, W/O Eyelet Ty Rap, W/O Eyelet Ty Rap, W/O Eyelet Ty Rap, W/Eyelet Ty Rap, W/Eyelet Ty Rap, W/Eyelet Ty Rap, W/Eyelet Wire, 18AWG, Red Wire, 18AWG, Blue Wire, 18AWG, Black Wire, 18AWG, Orange Wire, 18AWG, Orange Wire, Stripe, 18AWG, Red/Black Wire, 18AWG, Brown Wire, 18AWG, Blu/Blk Ty Rap, W/Eyelet Ty Rap, W/Eyelet Ty Rap, W/O Eyelet Ty Rap, W/O Eyelet Ty Rap, W/O Eyelet Ty Rap, W/Eyelet Ty Rap, W/O Eyelet Ty Rap,	7
25-10580-01 Ty Rap, W/Eyelet 87-11701-01 Assy, AC Power Cord Harn 25-10561-01 Nut, Wire 25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10609-01 Wire, 18AWG, Blue 34-10610-01 Wire, 18AWG, Black 34-1187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10615-01 Pin, Male, Molex Pin, Female, Molex	, 5
25-10561-01 Nut, Wire 25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10610-01 Wire, 18AWG, Blue 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	2
25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10610-01 Wire, 18AWG, Blue 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	1
25-10579-01 Ty Rap, W/O Eyelet 25-10580-01 Ty Rap, W/Eyelet 34-10608-01 Wire, 18AWG, Red 34-10609-01 Wire, 18AWG, Blue 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex 35-10615-01 Pin, Female, Molex	1
25-10580-01 34-10608-01 34-10609-01 34-10610-01 34-10908-01 34-11187-01 34-11187-01 34-1118-01 34-11718-01 35-10614-01 Pin, Male, Molex Pin, Female, Molex	15
34-10608-01 Wire, 18AWG, Red 34-10609-01 Wire, 18AWG, Blue 34-10908-01 Wire, 18AWG, Black 34-1187-01 Wire, 18AWG, Orange Wire, Stripe, 18AWG, Red/Black Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	5
34-10609-01 Wire, 18AWG, Blue 34-10610-01 Wire, 18AWG, Black 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	J
34-10610-01 Wire, 18AWG, Black 34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	
34-10908-01 Wire, 18AWG, Orange 34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	
34-11187-01 Wire, Stripe, 18AWG, Red/Black 34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	
34-11412-01 Wire, 18AWG, Brown 34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex 35-10615-01 Pin, Female, Molex	
34-11718-01 Wire, 18AWG, Blu/Blk 35-10614-01 Pin, Male, Molex Pin, Female, Molex	
35-10614-01 Pin, Male, Molex 35-10615-01 Pin, Female, Molex	
35-10615-01 Pin, Female, Molex	14
35-10617-01 Terminal, Female, Ouick Discoppect	5
- [mail of Quick Disconnect	2
41-10647-01 Conn, 12 Cir M, Molex 03-09-1122	1
41-10657-01 Conn, 6 Cir M, Molex 03-09-1063	1
41-10884-01 Conn, 12 Cir F, Molex 03-09-2121	1
87-10967-01 Assy, Cord, AC Power	1

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
87-11692-01	Assy, Harn Speaker	_1_
34-10906-01	Wire, 22AWG, Twisted, Brown/White	
35-10614-01	Pin, Male, Molex	2
35-10617-01	Terminal, Female, Quick Disconnect	2
25-10580-01	Ty Rap, W/Eyelet	2
41-10659-01	Conn, 3 Cir F, Molex 03-09-2038	1
38-10892-01	Assy, Interlock Swt, Back Panel	1
20-10863-01	Brkt, Interlock Switch	1
37-10893-01	Switch, Interlock	1
20-11376-02	Retainer, Marquee Plexi Upper 23	1
20-11377-02	Retainer, Marquee Plexi Lower 23	1
21-11666-03	Plexi, Front Screened	1
21-11694-01	Plexi Smoked 23. 75 x 20	1
21-11741-02	Plexi, Marquee Screened	1
22-11742-01	Decal, Side	2
25-10553-01	Bolt, Carriage, 3/16" 2", Black OX	4
25-10560-01	Nut, Wing, 3/16" #10-24	6
25-10568-01	Washer, Flat, #10 x 1/2"	23
25-10551-01	Bolt, Carriage, 3/16" x 1/2" Black O	1
25-11392-01	Bolt, Carriage, 3/16" x 1 1/4", Blk	16
25-10566-01	Screw, Wood, #8 x 5/8", Bx Dr Blk, OX	22
25-11613-01	Nut, #8-32	24
25-11721-01	Hook, Key	1
38-11728-02	Kit, Spares	1
18-11732-01	Screwdriver, BX DR #8 VACO TR-2	1
25-10566-01	Screw, Wood, #8 x 5/8", BX DR BLK, OX	6
67-11580-01	Fuse, 5AMP Slow Blow	1
67-10832-01	Fuse, 5AMP, 3AG	1

21-10831-01 22-10542-01 22-10544-01 34-10903-01 35-11096-01	Bezel, CRT, Formed Label, "Patent Notice" Label, "Unit Wired For"	1
22-10544-01 34-10903-01 35-11096-01	Label, "Patent Notice"	
22-10544-01 34-10903-01 35-11096-01	§	1
34-10903-01 35-11096-01		1
35-11096-01	Braid, Flat, Tinner Copper, 3/16"	10
72 11724 01	Lug, Ground	6
72-11734-01	Manual, Operator	1
38-11758-02	Assy, Shipping Cont. Raster Short	1
15-11179-01	Cap	2
15-11180-01	Pads, Corner	4
15-11181-01	Pallet Foam	1
15-11759-01	Sleeve, Game (29x33x72) 600DW	1
15-11760-01	Banding, Plastic 3/8"	
	The following parts are used on the Cocktail Table game cabinet ONLY:	
20-11420-01	Rail, CRT Mtg	2
21-11715-01	Plexi, Smoked Top	1
32-11427-01	Cabinet, W/Back	1
32-11428-01	Bracket, Glass Holder	1
32-11556-01	Bkt, Speaker	1
25-11722-01	Leveler, Leg	4
38-11439-01	Assy, Speaker	1
25-11414-01	Screw, Wood, #8-1 1/4", BX DR, BLK O	2
71-10834-01	Speaker	1
38-11441-01	Assy, Coin Box	1
20-10871-02	Coin Drawer	1
20-10872-02	Cover, Coin Drawer	1
38-11691-01	Assy, Ctl Pnl Plyr #1	1
20-11691-01	Ctl Pnl Plyr #1	1
22-11744-01	Decal, Ctl Pnl Plyr #1	1

Assy, Ctl Pnl Plyr #2 Ctl Pnl Plyr #2	1
Ctl Pnl Plyr #2	
-	1
Decal, Ctl Pnl Plyr #2	1
Assy, Power Supply Raster	1
Plate, Mntg P/S & Trans	1 .
Assy, Harn Ctl Pnl Inter	1
Ty Rap, W/O Eyelet	5
Ty Rap, W/Eyelet	2
Wire, 22AWG, Blk	
Wire, 22AWG, Green	
Wire, 22AWG, Yellow	
Wire, 22AWG, Purple	
Wire, 22AWG, Orange	
Wire, 22AWG, Grey	
Wire, 22AWG, Brown	
Wire, 22AWG, Blue	
Wire, 22AWG, White	
Pin, Male, Molex	1
Pin, Female, Molex	30
Conn, 15 Cir F, Molex 03-09-2153	1
Conn, 9 Cir M, Molex 03-09-1093	2
Assy, Harn Ctl Pnl #1	1
Assy, Harn Ctl Pnl #2	1
Wire, 22AWG/TC, Buss	ı
Wire, 22AWG, Black	ı
Wire, 22AWG, White	I
Wire, 22AWG, Green	1
Wire, 22AWG, Purple	į
Wire, 22AWG, Yellow	I I
Wire, 22AWG, Grey	
Wire, 22AWG, Brown	}
	Assy, Power Supply Raster Plate, Mntg P/S & Trans Assy, Harn Ctl Pnl Inter Ty Rap, W/O Eyelet Ty Rap, W/Eyelet Wire, 22AWG, Blk Wire, 22AWG, Green Wire, 22AWG, Purple Wire, 22AWG, Orange Wire, 22AWG, Grey Wire, 22AWG, Brown Wire, 22AWG, Blue Wire, 22AWG, White Pin, Male, Molex Pin, Female, Molex Conn, 15 Cir F, Molex 03-09-2153 Conn, 9 Cir M, Molex 03-09-1093 Assy, Harn Ctl Pnl #1 Assy, Harn Ctl Pnl #2 Wire, 22AWG, White Wire, 22AWG, White Wire, 22AWG, White Wire, 22AWG, White Wire, 22AWG, Green Wire, 22AWG, Purple Wire, 22AWG, Yellow Wire, 22AWG, Grey

		QTY.
34-10605-01	Wire, 22AWG, Blue	
34-10602-01	Wire, 22AWG, Orange	
35-10614-01	Pin, Male, Molex	9
41-10885-01	Conn, 9 Cir F, Molex 03-09-2092	1
25-10579-01	Ty Rap, W/O Eyelet	8
92-11740-01	Glass, Top Screened	1
20-11156-01	Grill, Heat Vent	2
23-11425-01	Tape, Foam 1.5"	
	·	
,		
-		

PARTS LIST ELECTRONIC BOARDS

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
38-11733-01	Assy, Boards NB	
38-11820-01	Assy, Game NB 8201 (NB)	1
81-11821-01	Assy, Game NB 8201	1
36-10621-01	Socket, 24 Pin, IC Dip Solder Tail	8
36-11784-01	Socket, 40 Pin Diptail	1
37-11824-01	Switch, Dip 8 Pos DC5V lA Uni-Aut	1
44-10679-01	IC, 74LS04	1
44-10680-01	IC, 74LS08	1
44-10683-01	IC, 74LS32	3
44-10689-01	IC, 74LS157	1
44-10690-01	IC, 74LS163	1
44-11028-01	IC, 74LS74	1
44-11029-01	IC, 74LS138	2
44-11036-01	IC, 7407	1
44-11340-01	IC, 74LS125	1
44-11343-01	IC, LM556	2
44-11478-01	IC, 74LS153	1
44-11483-01	IC, 74LS174	1
44-11486-01	IC, 74LS244	3
44-11487-01	IC, 74LS245	2
44-11492-01	IC, 74LS374	2
44-11825-01	IC, 74LS14	2
44-11827-01	IC, 74LS145	2
44-11828-01	IC, LM324	2
44-11829-01	IC, LM380	1
44-11830-01	IC, I4006B	1
44-11831-01	IC, I4066B	1
44-11832-01	IC, TMS-3615	1
44-11833-01	IC, Z-80A	1
44-11834-01	IC, 2114/4	2
53-10726-01	RES, 100 OHM 1/4W 5% C	7
53-10727-01	RES, 150 OHM 1/4W 5% C	4

PARTS LIST ELECTRONIC BOARDS

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
53-10731-01	RES, 330 OHM 1/4W 5% C	3
53-10732-01	RES, 470 OHM 1/4W 5% C	2
53-10735-01	RES, 1.5K OHM 1/4W 5% C	41
53-10737-01	RES, 2K OHM 1/4W 5% C	6
53-10746-01	RES, 10K OHM 1/4W 5% C	10
53-10749-01	RES, 20K OHM 1/4W 5% C	10
53-10756-01	RES, 47K OHM 1/4W 5% C	5
53-10924-01	RES, 33K OHM 1/4W 5% C	5
53-10928-01	RES, 100K OHm 1/4W 5% C	4
53-10931-01	RES, 200K OHM 1/4W 5% C	6
53-11308-01	RES, 510K OHM 1/4W 5% C	1
53-11836-01	RES, 510 OHM 1/4W 5% C	2
63-10782-01	CAP, .01mf 50V Disc 20%	1
63-10940-01	CAP, .001mf 50V Disc 20%	1
63-10993-01	CAP, 47mf 50V Electrolytic Radial	3
63-11100-01	CAP, .0luf 50V Film	3
63-11370-01	CAP, 10mf 50V Electrolytic	15
63-11837-01	CAP, lmf 50V Electrolytic	14
63-11838-01	CAP, 2.2mf 50V Electrolytic	3
63-11839-01	CAP, 470mf 50V Electrolytic	1
63-11840-01	CAP, .047mf 50V Disc	15
66-11841-01	Trans, 2SC-1815	1
80-11821-01	Board, NB-8201	1
87-11842-01	Assy, R. Cble Flat 50 Cir	2
44-11826-01	IC, 74LS136	1
05-11823-01	Assy, E Prom Kit NB-8201 (NB)	1
02-11823-01	E Prom, #1 NB	1
02-11823-02	E Prom, #2 NB	1
02-11823-03	E Prom, #3 NB	1
02-11823-04	E Prom, #4 NB	1
02-11823-05	E Prom, #5 NB	1
02-11823-06	E Prom, #6 NB	1
02-11823-07	E Prom, #7 NB	1
02-11823-08	E Prom, #8 NB	1

PARTS LIST ELECTRONIC BOARDS

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
38-11820-02	Assy, Game NB 8202 (NB)	1
81-11822-01	Assy, Game NB 8202	1
36-10620-01	Socket, 16 Pin, IC, Dip Solder Tail	2
36-10621-01	Socket, 24 Pin, IC, Dip Solder Tail	8
44-10677-01	IC, 74LS00	2
44-10679-01	IC, 74LS04	2
44-10680-01	IC, 74LS08	2
44-10686-01	IC, 74LS86	4
44-10687-01	IC, 74LS107	1
44-10688-01	IC, 74LS151	4
44-10689-01	IC, 74LS157	9
44-10690-01	IC, 74LS163	4
44-11028-01	IC, 74LS74	3
44-11029-01	IC, 74LS138	2
44-11032-01	IC, 74LS174	5
44-11341-01	IC, 7404	2
44-11487-01	IC, 74LS245	2
44-11490-01	IC, 74S283	3
44-11492-01	IC, 74LS374	3
44-11826-01	IC, 74LS136	1
44-11843-01	IC, 6301	2
44-11834-01	IC, 2114/4	8
53-10726-01	RES, 100 OHM 1/4W 5% C	1
53-10734-01	RES, 1K OHM 1/4W 5% C	1
53-11306-01	RES, 1.2K OHM 1/4W 5% C	2
63-10780-01	CAP, 470PF 50V Disc 20%	1
63-10790-01	CAP, 47mf 50v Electrolytic Axial	1
63-10940-01	CAP, .001mf 50V Disc 20%	2
63-11840-01	CAP, .047mf 50V Disc	16
69-11844-01	Crystal, 12 MHZ HC-18/U	1
80-11822-01	Board, NB-8202	1
05-11823-02	Assy, E Prom Kit NB-8201 (NB)	1
02-11823-09	E Prom, #9 NB	1
02-11823-10	E Prom, #10 NB	1

PARTS LIST ELECTRIONIC BOARDS

CINEMATRONICS PART NUMBER	DESCRIPTION	QTY.
02-11823-11	E Prom, #11 NB	_
02-11823-12	E Prom, #12 NB	1
02-11823-13	E Prom, #13 NB	1
02-11823-14	E Prom, #14 NB	1
02-11823-15	E Prom, #15 NB	1
02-11823-16	E Prom, #16 NB	1 1
	·	
*		

NAUGHTY BOY
BOARD EDGE CONNECTOR PIN-OUT LIST

EDGE CONN. PIN (J1)	<u>FUNCTION</u>	<u>TO</u>	WIRE COLOR
J1-A	Ground, Monitor	J6-1	Black
J1-1	Ground, Power Supply	J5 - 1	Black
J1-B	Ground, Volume Pot	J2-7	Black
J1-2	Ground, Connector Switch	J2-1	Black
J1-C	Not Used		
J1-3	Ground, Control Panel	J3-7	Black
J1-D	Speaker Ground	J4-1	Black
J1-4	Speaker Output	J4-2	Brown
J1-E	Not Used		
J1 - 5	Coin Switch	J2-2	Yellow
Jl-F	Not Used		
J1-6	Not Used		
J1-H	+12 Volts	J5-4	Yellow
J1-7	+12 Volts		~~
J1 - J	Volume Pot	J2-5	Red
J1-8	Volume Pot	J2-6	Blue
J1-K	+5 Volts	J5 - 2	Red
J1 - 9	+5 Volts, Counter	J2-4	Red
J1-L	Not Used		
J1-10	Not Used		
J1-M	Player Two - Up	J3-6	Violet
J1-11	Player One - Up	J3-10	Violet
J1-N	Player Two - Down	J3-4	Gray
J1-12	Player One - Down	J3-12	Gray
J1-P	Player Two - Right	J3-2	Blue
J1-13	Player One - Right	J3-14	Blue
J1-R	Player Two - Left	J3-1	Orange
J1-14	Player One - Left	J3-15	Orange


NAUGHTY BOY


BOARD EDGE CONNECTOR PIN-OUT LIST

EDGE CONN. PIN (J1)	FUNCTION	<u>TO</u>	WIRE COLOR
J1-S	Monitor - Red	J6-2	Ređ
J1-15	Player Two - Start	J3-8	White
J1-T	Monitor - Blue	J6-4	Blue
J1-16	Player One - Start	J3-9	Green
J1-U	Monitor - Green	J6-3	Green
J1-17	Player One - Fire	J3-11	Yellow
J1-V	Monitor Sync.	J6-5	White
J1-18	Player Two - Fire	J3-5	Yellow

APPENDIX A


Assembly Drawings
Schematics
and
Wiring Diagrams








40. 化二十四倍 海南山河南南南部部市 40. 40. 4.10 4.2%(1) (1. 4.2%(1) 4.4.4%(1) 4.4.4%(1) 4.4.4%


MICO JAPAN LEISURE CO., LTD.























PROPRIETARY

THIS DOCUMENT IS THE PROPERTY OF CINEMATRONICS INC. AND IS NOT TO BE REPRODUCED OR DISTRIBUTED WITHOUT WRITTEN AUTHORIZATION OF CINEMATRONICS

I	REVISIONS								
L	REV		DESCRIF	DATE	APPROVED				
L	8	ORIG.	REL.	3-25-82	the				

CONNECTOR	FROM	TO	COLDR	AWG	PIN	LENGTH	REMARKS
	31-1	(VDL)	(BLK)	(22)	(F)		À
Jı	J1 -2	(COUNTER)		(22)	(M)		<u>\$</u>
	J1-3	KT. SWITCH	GRY	22	M	20.D*	
COIN DOOR	JI-3	LFT. SWITCH	YELLOW	22	M	24.75	
MDLEX #	JI -4	(COUNTER)		(22)	(M)		<u> 3</u>
03-09-2092	JI -5	(VOL)	(RED)	(22)	(F)		<u>\$</u>
1 41-10885-01	J1 -6	(VDL)	(BLUE)	(22)	(F)		<u> </u>
2	J1-7	RT. SWITCH	BLK	22	F	20.0"	SWITCH GND
	J1-8	LAMP I	WHT 🔏	22	М	14.25	LIGHT
	J1-8	LAMPZ	WHT A	22	M	19.25	LIGHT
	J 1-9	LAMP (BRN 💪	22	M	14.25	LIGHT
	J1-9	LAMP 2	BRN 🔏	22	M	19.25	LIGHT
	LFT. SWITC	JI RT.SWITCH	BLK 2	22		30.75	JUMPER

ATO BE AMED AT NEXT ASSEMBLY. & STRIP BACK 3/8" FOR SOLDER A CINEMATRONICS PART NO.

NOTES

TOL. +1-0" -0.0"

MATERIAL:	DRAWN BY: TENNES	DATE			
	PROJECT ENGR:	DATE			
FINISH: BREAK ALL SHARP	RELEASE APPROV	DATE			
EDGES AND DEBURR ALL HOLES.	DO NOT SCALE DWG				
	TOLERANCE: UNLE	SS IED			

PROJECTION: SCALE:

CINEMATRONICS

DWG TITLE WIRE LIST
COIN DOOR HARNESS
UPRIGHT/CONTAIL JG
MODEL NO. DWG DWG NO. REV.
812E 88-11680-01 B

CODE IDENT.

REV. SHEET | OF

INC.

El Cajon Ca. 92020

3 REVISIONS DESCRIPTION DATE APPROVED PROPRIETARY A ORIG. REL. 4-14-82 /4/14 THIS DOCUMENT IS THE PROPERTY +016 OF CINEMATRONICS INC. AND IS LENGTH CHG'D ECO" 173 NOT TO BE REPRODUCED OR DISTRIBUTED WITHOUT WRITTEN D AUTHORIZATION OF CINEMATRONICS CONNECTOR FROM COLDR AWG PIN LENGTH REMARKS CONNECTOR FROM TO COLOR AWG PIN LENGTH REMARKS 70 PI-1/3 P2-7 PLACK 34.25 P2-1 P1-7 BLACK M C C P2-1 P1-2 P2-4 WHITE 22 34.25 P1-9 PROWN P2 PI P1-2 CRI- CATHODE P2-2 YELLOW P1-3 MAIN WIRE HARD! COIN DOOR P2-5 P1-4 YELLOW 22 3.0 PI-4 GREY M MOLEX PIN MOLEY PIN 03-09-1093 PI-3 P2-2 YELLOW 03-09-2092 P2-4 P1-2 MUITE 3425 1-10649-01 PI-4 1-10885-01P2-4 P2-3 GREY 34.25 CRY- AHODE P2-5 1 P1-5 P1-3 P1-4 YELLOW RED 22 CRI- ANOME P2-6 A P1-6 P1-4 PLUE P1-5 A P2-5 P2-7 & P1-1 PLACK RED 34.25 PI-6 /3 P2-6 POLUE P7-8 CR7-LATHORE P1-7 P2-1 PLACK P7-8 P1-8 RED M м P1-8 P2-8 RED P2-9 NOT USED В 8 P1-9 P2-1 BROWN 22 34-25 MATERIAL: El Cajon CINEMATRONICS PROJECT ENGN: DATE MELO DWG TITLE WIRE LIGT-ITHIS WIRES ARE TWISTED. RELEASE ARAMON DATE COIN DOOR INTERCONNECT 2. CATHODE SIDE - LIDE SIDE OF DIODE. DO NOT SCALE DWG UPRIGHT/COCKTAIL (1.4.41.8.) FINISH: CINEMATRONICS INC. PART NO. TOLERANCE: UNLESS OTHERWISE SPECIFIED MODEL HO DWG DWG NO. TOL: NOTES: UNLESS OTHERWISE SPECIFIED +1.0 PROJECTION: SCALE: FULL CODE IDENT. -0.0 SHEET OF 3 2

REVISIONS
REV DESCRIPTION DATE APPROVED
A ORIG REL ERN #13 3-24 \$L

34.82 /

B ECO 164 AND 24" TO PS

THIS DOCUMENT IS THE PROPERTY OF CIMEMATRONICS INC. AND IS MOT TO BE REPRODUCED OR DISTRIBUTED WITHOUT WRITTEN AUTHORIZATION OF CIMEMATRONICS INC.

 \mathbf{D}

В

CONNECTOR	FROM	TO	COLOR	AWG	PIN	LENGT	REMARKS
<u>P6</u>	P6-:1	P7 -3	BLK	22	M	15.75	
CPU BD	P6 - 1	P8-3	BLK	22	M	A	
MOLEX #	P6-2	P8-6	RED	22	M		
03-09-2062	P6-3	P8 -5	GRN	27	M		
11391-10954-01	P6-4	P8 -4	BLU	22	M		
	P6-5	P7 -1	THW	22	W	1	*
	P6-5	P7 -Z	THW	12	W	15.75	
	P6-6					-	NOT LISED
P7							
RASTER MON	P7 -1	P6-5	THW	22	F`)	
MOLEX # 09-50-7031	P7 -2	P6-5	THW	22	F	1/2	
1-11727-01	P7-3	P6-1	BLK	22	F		
	PB -1						NOT USED
<u>P8</u>	P8 -2						NOT USED
RASTER MON	P8-3	P6-1	BLK	22	F١	ì	
MOLEX#	P8-4	P6-4	BLUE	22	F		
09-50-7061 ^	P8-5	P6-3	GRN	22	F	A	
11 41-11724-a	P8-6	P6-Z	RED	22	F J		

DAAWN BY:

TENINGS

3.91

PROJECT ENGR:

CODE IDENT.

DATE

TOLERANCE

PROJECTION: SCALE:

CINEMATRONICS

INC. Co.

82020

DWG TITLE WIRE LIST—

DWG TITLE WIRE LIST—

DWG TITLE WIRE LIST—

DWG TITLE WIRE LIST—

DWG TOLERANCE UNIESS

OTHERAWGE UNIESS

OTHERAWGE SPECIFIED

MOOEL NO. DWG DWG NO.

SIZE BB-11711-01 B

CODE IDENT.

SHEET | OF |

3. M= MALE PIN, MOLEY PIN 02-09-2118.

♠ F= CRIMP TERMINALS MOLEY P/N 08-50-0106

♠ P/N 35-10880-01.

/ CINEMATRONICS PART NO.

NOTES: UNLESS OTHERWISE SPECIFIED


4


3


2


2


- 1



































PROPRIETARY

THIS DOCUMENT IS THE PROPERTY OF CINEMATRONICS INC. AND IS NOT TO BE REPRODUCED OR DISTRIBUTED WITHOUT WRITTEN AUTHORIZATION OF CINEMATRONICS INC.

REVISIONS							
REV	DESCRIPTION	DATE	APPROVED				
Α	DRIC RELEASE ERN#013	3/25/82	hit				

CONNECTOR	FROM	TO	COLOR	AWG	PIN	LENGTH	REMARKS
P4 MAIN WIRE HARN MOLEX P/N 03-09-2038 241-10159-01	P4 - 1 P4 - 2 P4 - 3	SPEAKER SPEAKER	BRN WHT	72 22	M	45.0 45.0	ИЗЕД Д Д

A CINEMATRONICS PART NO.

WIRES TERMINATE AT SPEAKER END WITH WITH FEMALE QUICK DISCONNECTS,
CINEMATRONICS PIN 35-IDGI7-01

NOTES:

NITH

BREAK ALL SHARP EDGES AND DEBURR ALL HOLES.

+LO"
-0-0"

MATERIAL:

FINISH:

PROJECT ENGR: DATE VIS/NZ
PROJECT ENGR: DATE VIS/NZ
RELEASE APPROV. DATE

DO NOT SCALE DWG
TOLERANCE: UNLESS
OTHERWISE SPECIFIED

PROJECTION: SCALE:

CINEMATRONICS

DWG TITLE

INC. El Cajon Ca. 92020

WIRE LIST-(COCKTAIL)
SPEAKER HARNESS (JG)

MODEL NO. DWG DWG NO.
SIZE 80-11692-01 A

CODE IDENT.

SHEET OF

